

## MENU of Marwell AMR Adapters

a) **1000-0-R7** with **M-105FF** coupler. Allows a Marwell extender adapter with small top mounted enclosure to be installed in either a ring or ringless meter socket. \_\_\_\_\_



b) **1000-R4-TIMER**. Extender adapter with 35 amp relay and programmable control timer. Used to control electric water heater when AMR meter is used to replace to timer/meter. \_\_\_\_\_



c) **1000-R4-RELAY**. Extender adapter with 35 amp relay to be controlled with output contacts from TOU meter. \_\_\_\_\_



d) **1000-0-R4-BLP**. Extender adapter with BLP 200 amp disconnect switch. Requires control circuit by others. \_\_\_\_\_



e) **1000-0-R4-RJ11-RECESS**. Extender adapter for socket meters with RJ11 cable. Allows installation of phone line without modifying meter socket. \_\_\_\_\_



**Contact Marwell  
for  
additional  
information**

f) **2000-3W-RJ11**. A-Base to socket adapter with RJ11 jack and junction box for connection to phone line. Primarily for outdoor applications. \_\_\_\_\_



g) **2500-3W-SP-2885-6**. A-Base to socket adapter for single phase meters with modems. Cable exit notch allows cable to be routed out of meter base. Primarily for indoor applications. \_\_\_\_\_



h) **2200N-RJ11**. Polyphase A-Base to socket adapter with RJ11 jack and junction box for connection to phone line. Primarily for outdoor applications. \_\_\_\_\_



i) **2200N-SP2885-6**. A-Base to socket adapter for polyphase meters with modems. Cable exit notch allows cable to be routed out of meter base. Primarily for indoor applications. \_\_\_\_\_



For information email [sales@marwellcorp.com](mailto:sales@marwellcorp.com)



*World's leading manufacturer of UL Listed meter socket adapters*

**MARWELL CORPORATION**



PO BOX 139 \* MENTONE, CA 92359 \* 909-794-4192 \* FAX 909-794-0250